

October 27, 2016

Setting up Email Alerts on the Phoenix



October 27, 2016

Firstly, right click and go to **Main Menu**, then **Configure** and **Account Setup**. Once here you will need to input **your email address** into the users email section.

Account Setup					
Adimin 1	2 3 4 able pire pords	<u>S</u> 6 7 8 9 10 Admin Paseword Satup (distrast.gmz.com			
	OK)	Cancel			

Now go to **Event Setup** in the Configure menu and choose **Motion Detection** at the top and **Receiver Setup** at the bottom.

Tick the **enable** box and tick the box relating to the **correct user/ email address**.

Event Setup								
		ao loss	Motion	Detectio	on Sy	stem		_
	\triangleleft	CH01	CH02	C	HOS (CH04	\triangleright	
			60	Contra				
	🖌 Enable							
	🗹 Admin							
	🔵 ch1							
	User2							
	User3							
	User4							
	User5							
2	User6							
	User7							
Po	User3							
	User9							
	User10							
	(OK	3		Cancel			
	0000000		<u> </u>		<u> </u>			
Resur	ne Preset [0			0 >		0
	Mail to 🌔	Receive	er Setup		Notificatio	n Setup,		
	(OK	3		Cancel			



October 27, 2016

Please ensure	that motion	detection is	enabled a	s below:
r ieuse enisare	that motion	actection is	chabica c	5 5010

Event Setup					
	deo Loss CH01	Motion CH02	Detection CH03	System CH04	
		Se	tup		
Enable	V				
Notification					
		Event	Handler		
Log	\checkmark		\checkmark		
Event Record	(CH01 🗸	CHO2	CHO3	-) (CH04 -) (Disable 🖂
Рорир	Disable 🗸) (Disable	🕞 (Disabla) (Disable ~	Disable 🖂
Popup Channel	CHO1	CHO2	CHOS	CH04 -	Relative 🖓
Buzzer					
PTZ	Disable 🗸) (Disable	🕑 (Disable) (Disable -	Disable 🖂
Go Preset					
Resume Preset					
Mail to	Receiv	er Setup	Noti	fication Setup	
OK Cancel					

To setup SMTP settings right click and go to **Configure** and then **Network Setup**, then click the **Email Setup** towards the bottom of the page.

In here you will need to fill out the relevant information, an example is shown below of these settings:

(HTTP	DDNS	NTP	Mail Setup	FIP
🗹 Enable				
SMTP Server:		smip.gmx.com	1 46	5 Ď 🍼 SSL
User:		ddstəst@gmx.	com	
Password:		000000000		
Sender's e-Mail:		ddstest@gmx.	com	Test

Once this has been done click the **OK** button, this will save your settings and email alerts should be sent when motion detection is triggered.